TALON Series L.E.D. Perimeter Lights



WIRING INSTRUCTIONS			
RED	Apply to Positive for Activation of COLOUR 1		
PURPLE	Apply to Positive for Activation of COLOUR 2		
Combine both RED + PURPLE wires to Activate both COLOUR 1 + 2			
BLACK	Apply to Negative for Ground		
WHITE	Apply to Negative for Dimming		
BLUE	Momentarily Apply to Negative for Pattern Change		
Connect BLUE wires to SYNCHRONISE Multiple Units			
YELLOW	Apply to Negative for Steady-On		
Momentarily Apply BLUE wire to Negative to change the COLOUR of Steady-On function, when activated.			

WARNING NOTICE HIGH INTENSITY BRIGHTNESS | DO NOT STARE DIRECTLY INTO LIGHT

PATTERN LIST					
SINGLE COLOUR		DUAL COLOUR			
P1	FULL – Fast Single Flash 120FPM *A*	P1	FULL – Fast Single Flash 120FPM *A*		
P2	FULL – Fast Single Flash 120FPM * B *	P2	FULL – Fast Single Flash 120FPM *B*		
P3	FULL – Fast Double Flash 120FPM *A*	P 3	P3 FULL – Fast Double Flash 120FPM *A*		
P4	FULL – Fast Double Flash 120FPM * B *	P4	4 FULL – Fast Double Flash 120FPM *B*		
P5	FULL – Fast Quad Flash 120FPM *A*	P5	FULL – Fast Quad Flash 120FPM *A*		
P6	FULL – Fast Quad Flash 120FPM *B*	P6	FULL – Fast Quad Flash 120FPM *B*		
P7	FULL – Slow Single Flash 75FPM *A*	P7	FULL – Slow Single Flash 75FPM *A*		
P8	FULL – Slow Single Flash 75FPM * B *	P8	FULL – Slow Single Flash 75FPM *B*		
P 9	FULL – Slow Double Flash 75FPM *A*	P9	FULL – Slow Double Flash 75FPM *A*		
P10	FULL – Slow Double Flash 75FPM * B *	P10	0 FULL – Slow Double Flash 75FPM * B *		
P11	FULL – Slow Quad Flash 75FPM * A *	P11	FULL – Slow Quad Flash 75FPM *A*		
P12	FULL – Slow Quad Flash 75FPM *B*	P12	FULL – Slow Quad Flash 75FPM *B*		
P13	FULL – Steady-Burn @ 50% *COLOUR 1*	P13	FULL – Steady-Burn @ 50% *COLOUR 1*		
P14	OFF	P14	FULL – Steady-Burn @ 50% *COLOUR 2*		
Different Flash Patterns can be selected for RED, PURPLE and RED+PURPLE activation modes.		P15	OFF		

GROUPING		PROGRAMMING	
SIMULTANEOUS GROUPING	To Simultaneously flash all your lights together in one group with the same pattern at the same time, select the exact same PATTERN for each light featuring the same group, for example, all " A " or all " B ".	NEXT PATTERN	Apply BLUE wire to Negative for < 1 Second
		PREVIOUS PATTERN	Apply BLUE wire to Negative for ≥ 2 Seconds
ALTERNATING GROUPING	To Alternate flash your lights in two separate groups, select "A" pattern for your first group of lights, and select "B" pattern for your second group but both groups must feature the same PATTERN to allow the two groups to alternate flash.	FACTORY RESET	Apply BLUE wire to Negative for ≥ 4 Seconds
		DEACTIVATE	Apply BLUE wire to Negative for > 5 Seconds